



Pull Fanntum liner upward from opposite sides past the top horizontal wire of the basket to determine the desired amount of fold needed to toughly secure the liner to the basket.



Once the amount of fold is determined, attach the liner using hog ring staples approximately $\frac{3}{4}$ inch from the outside edge of the lifting loops. Make sure to staple on each side of the lifting loop. When complete rotate 180 degrees and repeat at each lifting handle.



Once all sides are attached at the lifting loops, pull liner tight as needed between loops and attach liner as needed to ensure desired fit.



Due to variation in fabric and wire baskets, sometimes a Z-fold/ pleat may be required. To tighten liner fabric to the top horizontal wire, pleat the material as needed and secure with hog ring staple.

Note:

*Failure to follow the assembly instructions may result in unsatisfactory fit and function of the container.

*When planting remove fabric from outside of wire basket.